
2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000


PRODUCT ADVANTAGES



SERIES CHARACTERISTICS

| Installation size / Variant | | |
|--|--------|---------|
| | GH60XX | GHK60XX |
| Position maintenance by means of clamp- ing element | | • |
| 10 million maintenance-free cycles (max.) | • | • |
| + 💭 Inductive sensor | • | • |
| Hagnetic field sensor | • | • |
| IP 40 IP40 | • | • |

BENEFITS IN DETAIL



1 Mounting block

- mounting for inductive proximity switch

2 Mounting and positioning

- mounting possible from several sides for versatile positioning
- 3 Removable centering sleeves
 - quick and economical positioning of the gripper fingers

(4) Gripper jaw

individual gripper finger mounting

5 Precise long T-Slot guides

- high forces and moments capacity

6 Drive

- two double-acting pneumatic cylinders
- synchronized by gearwheel

7 Energy supply

- possible from several sides
- CAUTION: always operate long stroke gripper with supplied exhaust air flow control valve (speed regulation)

8 Robust, lightweight housing

- Hard-coated aluminum alloy

TECHNICAL DATA

| | Stroke per jaw | Gripping force | Weight | IP class |
|-------------------|----------------|----------------|-------------|----------|
| Installation size | [mm] | [N] | [kg] | |
| GH6000 | 20 - 80 | 120 - 155 | 0,3 - 0,75 | IP40 |
| GH6100 | 40 - 80 | 370 - 530 | 1,5 - 2,2 | IP40 |
| GH6200 | 40 - 150 | 900 - 1400 | 3,3 - 7,5 | IP40 |
| GH6300 | 60 - 150 | 1520 - 2270 | 7 - 10,5 | IP40 |
| GH6400 | 60 - 200 | 2600 - 3400 | 10,4 - 22,7 | IP40 |


FURTHER INFORMATION IS AVAILABLE ONLINE



All information just a click away at: www.zimmer-group.com. Find data, illustrations, 3D models and operating instructions for your installation size using the order number for your desired product. Quick, clear and always up-to-date.


2-JAW PARALLEL GRIPPERS WITH LONG STROKE INSTALLATION SIZE GH6280

PRODUCT SPECIFICATIONS




YOU CAN FIND RECOMMENDED ACCESSORIES ON THE FOLLOWING PAGES

| | Technical data | | |
|---|----------------|---------|--|
| Order no. | GH6280-B | GHK6280 | |
| Stroke per jaw [mm] | 80 | 80 | |
| Gripping force in closing [N] | 1280 | 1280 | |
| Gripping force in opening [N] | 1100 | 1100 | |
| Retention force in case of drop in pressure [N] | | 640 | |
| Closing time [s] | 0.4 | 0.4 | |
| Opening time [s] | 0.4 | 0.4 | |
| Permissible weight per jaw max [kg] | 2.5 | 2.5 | |
| Length of the gripper fingers max. [mm] | 250 | 250 | |
| Repetition accuracy +/- [mm] | 0.05 | 0.05 | |
| Operating pressure min. [bar] | 3 | 3 | |
| Operating pressure max. [bar] | 8 | 8 | |
| Nominal operating pressure [bar] | 6 | 6 | |
| Operating temperature min. [°C] | 5 | 5 | |
| Operating temperature max. [°C] | +80 | +80 | |
| Air volume per cycle [cm ³] | 367 | 367 | |
| Weight [kg] | 4.8 | 5.3 | |



2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 - ACCESSORIES

ACCESORIES



RECOMMENDED ACCESSORIES GH6000

| Pos. | Order no. | Accessories | Pos. | Order no. | Accessories |
|-------|--------------------------|--|--------|--------------------|---|
| 1 | UB5004AL | * Universal jaw aluminium | 9 | NJ6.5-E2S | ** Inductive proximity switch - Connector M8 |
| 1 | UB5004ST | * Universal jaw steel | 10 | NJ6.5-E2-01 | ** Inductive proximity switch - Cable 5 m |
| 2 | WB5004L | * Changeable jaw, loose-part-set | 11 | MFS01-S-KHC-P1-PNP | Magnetic field sensor angled, cable 0.3 m - M8 connector |
| 3 | WB5004F | * Changeable jaw, fix-part | 12 | MFS01-K-KHC-P1-PNP | Magnetic field sensor angled, cable 5 m |
| 4 | EB5004ST | * Steel adjustment jaw | 13 | MFS02-S-KHC-P1-PNP | Magnetic field sensor straight, cable 0.3 m - M8 connecto |
| 4 | EB5004AL | * Aluminum adjustment jaw | (14) | MFS02-K-KHC-P1-PNP | Magnetic field sensor straight, cable 5 m |
| 5 | APGH6000 | Adapter plate | 15 | KAG500 | Plug-in connector Straight Cable 5m - Socket M8 (female |
| 6 | UB6000-B | Universal jaw set aluminium | 16 | KAW500 | Plug-in connector Angled Cable 5m - Socket M8 (female |
| 7 | DSV1-8E | Pressure safety valve with quick exhaust | 17 | S8-G-3 | Plug-in connector customizable Straight - Connector Ma |
| 8 | DSV1-8 | Pressure safety valve | 18 | S12-G-3 | Plug-in connector customizable Straight - Connector M1 |
| *in c | onjunction with pos. (5) | | * * nc | ot with GH6020 | |

2

www.zimmer-group.com > Data, Drawings, 3-D Models, Operating Instructions

RECOMMENDED ACCESSORIES GH6100

| Pos. | Order no. | Accessories |
|------|------------|--|
| 1 | UB5006AL * | Universal jaw aluminium |
| 1 | UB5006ST * | Universal jaw steel |
| 2 | WB5006L * | Changeable jaw, loose-part-set |
| 3 | WB5006F * | Changeable jaw, fix-part |
| 4 | EB5006ST * | Steel adjustment jaw |
| 4 | EB5006AL * | Aluminum adjustment jaw |
| 5 | APGH6100 | Adapter plate |
| 6 | UB6100-B | Universal jaw set aluminium |
| 7 | DSV1-8E | Pressure safety valve with quick exhaust |
| 8 | DSV1-8 | Pressure safety valve |

| Pos. | Order no. | Accessories |
|------|--------------------|--|
| 9 | NJ8-E2S | Inductive proximity switch - Connector M8 |
| 10 | NJ8-E2 | Inductive proximity switch - Cable 5 m |
| (11) | MFS01-S-KHC-P1-PNP | Magnetic field sensor angled, cable 0.3 m - M8 connector |
| 12 | MFS01-K-KHC-P1-PNP | Magnetic field sensor angled, cable 5 m |
| 13 | MFS02-S-KHC-P1-PNP | Magnetic field sensor straight, cable 0.3 m - M8 connector |
| 14 | MFS02-K-KHC-P1-PNP | Magnetic field sensor straight, cable 5 m |
| 15 | KAG500 | Plug-in connector Straight Cable 5m - Socket M8 (female) |
| 16 | KAW500 | Plug-in connector Angled Cable 5m - Socket M8 (female) |
| (17) | S8-G-3 | Plug-in connector customizable Straight - Connector M8 |
| 18 | S12-G-3 | Plug-in connector customizable Straight - Connector M12 |

*in conjunction with pos. 5

RECOMMENDED ACCESSORIES GH6200

| Pos. | Order no. | Accessories |
|------|-----------|--|
| 1 | UB5008AL | * Universal jaw aluminium |
| 1 | UB5008ST | * Universal jaw steel |
| 2 | WB5008L | * Changeable jaw, loose-part-set |
| 3 | WB5008F | * Changeable jaw, fix-part |
| 4 | EB5008ST | * Steel adjustment jaw |
| 4 | EB5008AL | * Aluminum adjustment jaw |
| 5 | APGH6200 | Adapter plate |
| 6 | UB6200-B | Universal jaw set aluminium |
| 7 | DSV1-8E | Pressure safety valve with quick exhaust |
| 8 | DSV1-8 | Pressure safety valve |

*in conjunction with pos. 5

RECOMMENDED ACCESSORIES GH6300

| Pos. | Order no. | Accessories |
|------|-----------|---|
| 1 | UB5010ST | * Universal jaw steel |
| 1 | UB5010AL | * Universal jaw aluminium |
| 2 | WB5010L | * Changeable jaw, loose-part-set |
| 3 | WB5010F | * Changeable jaw, fix-part |
| 4 | EB5010ST | * Steel adjustment jaw |
| 4 | EB5010AL | * Aluminum adjustment jaw |
| 5 | APGH6300 | Adapter plate |
| 7 | DSV1-8E | Pressure safety valve with quick exhaust |
| 8 | DSV1-8 | Pressure safety valve |
| 9 | NJ8-E2S | Inductive proximity switch - Connector M8 |

*in conjunction with pos. 5

RECOMMENDED ACCESSORIES GH6400

| Pos. | Order no. | Accessories |
|------|-----------|--|
| 1 | UB5016ST | * Universal jaw steel |
| 1 | UB5016AL | Universal jaw aluminium |
| 2 | WB5016L | Changeable jaw, loose-part-set |
| 3 | WB5016F | Changeable jaw, fix-part |
| 4 | EB5016ST | * Steel adjustment jaw |
| 4 | EB5016AL | Aluminum adjustment jaw |
| 5 | APGH6400 | Adapter plate |
| 7 | DSV1-8E | Pressure safety valve with quick exhaust |
| 8 | DSV1-8 | Pressure safety valve |
| 9 | NJ8-E2S | Inductive proximity switch - Connector M8 |

*in conjunction with pos. 5

| Pos. | Order no. | Accessories |
|------|--------------------|--|
| 9 | NJ8-E2S | Inductive proximity switch - Connector M8 |
| 10 | NJ8-E2 | Inductive proximity switch - Cable 5 m |
| (11) | MFS01-S-KHC-P1-PNP | Magnetic field sensor angled, cable 0.3 m - M8 connector |
| 12 | MFS01-K-KHC-P1-PNP | Magnetic field sensor angled, cable 5 m |
| 13 | MFS02-S-KHC-P1-PNP | Magnetic field sensor straight, cable 0.3 m - M8 connector |
| 14 | MFS02-K-KHC-P1-PNP | Magnetic field sensor straight, cable 5 m |
| 15 | KAG500 | Plug-in connector Straight Cable 5m - Socket M8 (female) |
| 16 | KAW500 | Plug-in connector Angled Cable 5m - Socket M8 (female) |
| 17) | S8-G-3 | Plug-in connector customizable Straight - Connector M8 |
| 18 | S12-G-3 | Plug-in connector customizable Straight - Connector M12 |

| Pos. | Order no. | Accessories |
|------|--------------------|--|
| 10 | NJ8-E2 | Inductive proximity switch - Cable 5 m |
| 11 | MFS01-S-KHC-P1-PNP | Magnetic field sensor angled, cable 0.3 m - M8 connector |
| 12 | MFS01-K-KHC-P1-PNP | Magnetic field sensor angled, cable 5 m |
| 13 | MFS02-S-KHC-P1-PNP | Magnetic field sensor straight, cable 0.3 m - M8 connector |
| (14) | MFS02-K-KHC-P1-PNP | Magnetic field sensor straight, cable 5 m |
| 15 | KAG500 | Plug-in connector Straight Cable 5m - Socket M8 (female) |
| 16 | KAW500 | Plug-in connector Angled Cable 5m - Socket M8 (female) |
| 17) | S8-G-3 | Plug-in connector customizable Straight - Connector M8 |
| 18 | S12-G-3 | Plug-in connector customizable Straight - Connector M12 |


| Pos. | Order no. | Accessories |
|------|--------------------|--|
| 10 | NJ8-E2 | Inductive proximity switch - Cable 5 m |
| 11 | MFS01-S-KHC-P1-PNP | Magnetic field sensor angled, cable 0.3 m - M8 connector |
| 12 | MFS01-K-KHC-P1-PNP | Magnetic field sensor angled, cable 5 m |
| 13 | MFS02-S-KHC-P1-PNP | Magnetic field sensor straight, cable 0.3 m - M8 connector |
| 14 | MFS02-K-KHC-P1-PNP | Magnetic field sensor straight, cable 5 m |
| 15 | KAG500 | Plug-in connector Straight Cable 5m - Socket M8 (female) |
| 16 | KAW500 | Plug-in connector Angled Cable 5m - Socket M8 (female) |
| 17 | S8-G-3 | Plug-in connector customizable Straight - Connector M8 |
| 18 | S12-G-3 | Plug-in connector customizable Straight - Connector M12 |
| | , | |

2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 FUNCTIONAL DESCRIPTION



 (\mathbf{I})

GRIPPING COMPONENTS



Universal jaws – UB5000

Can be used immediately or for individual reprocessing

The gripper blanks are available in aluminum (AL) and steel (ST) versions and are installed directly on the gripper using the screws in the scope of delivery. The fits for the centering sleeves are already in place for this purpose. One universal jaw is required for each gripper jaw.

Adjustment jaws - EB5000


For tool-free adaptation of the gripper range

By manually activating the locking mechanism, which is pre-tensioned by a spring, the adjustment jaw can be moved within a grid of detent notches that has a number scale. Depending on the forces and torques that apply, the adjustment jaws are available in aluminum (AL) and steel (ST) versions. One adjustment jaw is required for each gripper jaw.

Interchangeable jaws - WB5000

Enable fast change of individual gripper fingers

For each gripper jaw, a fixed part and at least one loose part set is needed, depending on the number of gripper fingers to be changed. Manual locking via the Torx wrench included in the scope of delivery of the fixed part can take place from two sides.




THE GRIPPING COMPONENTS CAN BE COMBINED!

The gripping components listed above can be combined with each other. For connection to the gripper, the adapter plate (5), which is included in the recommended accessories for the gripper, is required.




GRIPPING COMPONENTS



Universal jaws - UB6000-B

Can be used immediately or for individual reprocessing

The gripper blanks are available in an aluminum (AL) version and are installed directly on the gripper using the screws in the scope of delivery. The fits for the centering sleeves are already in place for this purpose. One universal jaw set is required for each gripper.




Pressure safety valve – DSV

Ensures safe retention of force and position if the system pressure drops

The integrated double check valve, which can be unlocked, retains the system pressure of the gripper in case of EMERGENCY STOP. To ensure the function, the valve must be installed as close to the gripper's air connection as possible. In variant E, two pushbuttons are installed that allow for controlled bleeding of the gripper.


2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 FUNCTIONAL DESCRIPTION

SENSORS




Inductive sensors - NJ

The mounting block is aligned to the cam switch, and the sensor is guided into the mounting block until the required switching distance to the cam switch is reached. Fine adjustment can be made by moving the mounting block again. The sensors are available in versions with 5 m cables with exposed leads and 0,3 m cable with connector, as well as with direct plug orientation.




Clamping bracket – KHA

The KHA can be used as an alternative to installing the sensor via the mounting block. The sensor is inserted into the clamping bracket as far as it will go and secured. Tuning to the cam switch then takes place. Fine adjustment can be made by moving the clamping bracket again.



MFS01



1-point magnetic field sensors - MFS


For non-contact sensing of the piston position

These sensors are installed in the C-groove of the gripper and detect the magnet attached to the piston of the gripper. To ensure use in a wide variety of space conditions, the sensors are available in two variants. While the horizontal MFS02, with straight cable outlet, disappears into the C-groove of the gripper almost completely, the vertical MFS01 is taller, but has a cable outlet that is offset at an angle of 90°. The variants are available in versions with 5 m cables with exposed leads and 0,3 m cable with connector.

2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 FUNCTIONAL DESCRIPTION



CONNECTIONS / OTHER



Centering sleeves


For defined position measurement of the gripper fingers


The centering sleeves are inserted into the fits of the gripper jaws to define the position of the gripper fingers. The centering sleeves are comparable to a pin connection.

2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 GRIPPER FINGER LENGTH




MAXIMUM GRIPPER FINGER LENGTH






Example 1


Vertical force application point a = 0 mm b = 200 mm






Example 2

Horizontal force application point a = 160 mm b = 0 mm




а

b




Example 3


Maximum permissible projection a = 96 mm b = 160 mm



GRIPPING FORCE AS A FUNCTION OF GRIPPER FINGER LENGTH



Gripping force diagram



Example 4

Resulting gripper finger length for determining the gripping force

a = 55 mm

b = 58 mm

 $x = \sqrt{55^2 + 58^2} = 80 => 435 N$

The specified maximum gripper jaw length in the gripper technical data refers to a vertical (b) alignment of the gripper jaws. With a horizontal (a) overhang, the maximum gripper jaw length is reduced accordingly. The table shows the maximum gripper jaw lengths of the individual sizes. If the required gripper jaw length lies within the tinted area of the gripping force diagram, increased wear must be expected - possibly reduce pressure.

TECHNICAL DATA

| | Permissible weight per jaw max | Length of the gripper fingers max. vertical (b) | Length of the gripper fingers max. horizontal (a) |
|-------------------|--------------------------------|--|--|
| Installation size | [kg] | [mm] | [mm] |
| GH6000 | 0.3 | 150 | 120 |
| GH6100 | 1 | 200 | 160 |
| GH6200 | 2.5 | 250 | 200 |
| GH6300 | 3.5 | 300 | 240 |
| GH6400 | 6 | 400 | 320 |