
2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000


PRODUCT ADVANTAGES



SERIES CHARACTERISTICS

Installation size / Variant		
	GH60XX	GHK60XX
Position maintenance by means of clamp- ing element		•
10 million maintenance-free cycles (max.)	•	•
+ 💭 Inductive sensor	•	•
Hagnetic field sensor	•	•
IP 40 IP40	•	•

BENEFITS IN DETAIL



1 Mounting block

- mounting for inductive proximity switch

2 Mounting and positioning

- mounting possible from several sides for versatile positioning
- 3 Removable centering sleeves
 - quick and economical positioning of the gripper fingers

(4) Gripper jaw

individual gripper finger mounting

5 Precise long T-Slot guides

- high forces and moments capacity

6 Drive

- two double-acting pneumatic cylinders
- synchronized by gearwheel

7 Energy supply

- possible from several sides
- CAUTION: always operate long stroke gripper with supplied exhaust air flow control valve (speed regulation)

8 Robust, lightweight housing

- Hard-coated aluminum alloy

TECHNICAL DATA

	Stroke per jaw	Gripping force	Weight	IP class
Installation size	[mm]	[N]	[kg]	
GH6000	20 - 80	120 - 155	0,3 - 0,75	IP40
GH6100	40 - 80	370 - 530	1,5 - 2,2	IP40
GH6200	40 - 150	900 - 1400	3,3 - 7,5	IP40
GH6300	60 - 150	1520 - 2270	7 - 10,5	IP40
GH6400	60 - 200	2600 - 3400	10,4 - 22,7	IP40


FURTHER INFORMATION IS AVAILABLE ONLINE



All information just a click away at: www.zimmer-group.com. Find data, illustrations, 3D models and operating instructions for your installation size using the order number for your desired product. Quick, clear and always up-to-date.


2-JAW PARALLEL GRIPPERS WITH LONG STROKE INSTALLATION SIZE GH6360

PRODUCT SPECIFICATIONS




YOU CAN FIND RECOMMENDED ACCESSORIES ON THE FOLLOWING PAGES

	Technical data		
Order no.	GH6360-B	GHK6360	
Stroke per jaw [mm]	60	60	
Gripping force in closing [N]	1840	1840	
Gripping force in opening [N]	1520	1520	
Retention force in case of drop in pressure [N]		640	
Closing time [s]	0.4	0.4	
Opening time [s]	0.4	0.4	
Permissible weight per jaw max [kg]	3.5	3.5	
Length of the gripper fingers max. [mm]	300	300	
Repetition accuracy +/- [mm]	0.05	0.05	
Operating pressure min. [bar]	3	3	
Operating pressure max. [bar]	8	8	
Nominal operating pressure [bar]	6	6	
Operating temperature min. [°C]	5	5	
Operating temperature max. [°C]	+80	+80	
Air volume per cycle [cm ³]	486	486	
Weight [kg]	7	7.5	



2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 - ACCESSORIES

ACCESORIES



RECOMMENDED ACCESSORIES GH6000

Pos.	Order no.	Accessories	Pos.	Order no.	Accessories
1	UB5004AL	* Universal jaw aluminium	9	NJ6.5-E2S	** Inductive proximity switch - Connector M8
1	UB5004ST	* Universal jaw steel	10	NJ6.5-E2-01	** Inductive proximity switch - Cable 5 m
2	WB5004L	* Changeable jaw, loose-part-set	11	MFS01-S-KHC-P1-PNP	Magnetic field sensor angled, cable 0.3 m - M8 connector
3	WB5004F	* Changeable jaw, fix-part	12	MFS01-K-KHC-P1-PNP	Magnetic field sensor angled, cable 5 m
4	EB5004ST	* Steel adjustment jaw	13	MFS02-S-KHC-P1-PNP	Magnetic field sensor straight, cable 0.3 m - M8 connecto
4	EB5004AL	* Aluminum adjustment jaw	(14)	MFS02-K-KHC-P1-PNP	Magnetic field sensor straight, cable 5 m
5	APGH6000	Adapter plate	15	KAG500	Plug-in connector Straight Cable 5m - Socket M8 (female
6	UB6000-B	Universal jaw set aluminium	16	KAW500	Plug-in connector Angled Cable 5m - Socket M8 (female
7	DSV1-8E	Pressure safety valve with quick exhaust	17	S8-G-3	Plug-in connector customizable Straight - Connector Ma
8	DSV1-8	Pressure safety valve	18	S12-G-3	Plug-in connector customizable Straight - Connector M1
*in c	onjunction with pos. (5)		* * nc	ot with GH6020	

2

www.zimmer-group.com > Data, Drawings, 3-D Models, Operating Instructions

RECOMMENDED ACCESSORIES GH6100

Pos.	Order no.	Accessories
1	UB5006AL *	Universal jaw aluminium
1	UB5006ST *	Universal jaw steel
2	WB5006L *	Changeable jaw, loose-part-set
3	WB5006F *	Changeable jaw, fix-part
4	EB5006ST *	Steel adjustment jaw
4	EB5006AL *	Aluminum adjustment jaw
5	APGH6100	Adapter plate
6	UB6100-B	Universal jaw set aluminium
7	DSV1-8E	Pressure safety valve with quick exhaust
8	DSV1-8	Pressure safety valve

Pos.	Order no.	Accessories
9	NJ8-E2S	Inductive proximity switch - Connector M8
10	NJ8-E2	Inductive proximity switch - Cable 5 m
(11)	MFS01-S-KHC-P1-PNP	Magnetic field sensor angled, cable 0.3 m - M8 connector
12	MFS01-K-KHC-P1-PNP	Magnetic field sensor angled, cable 5 m
13	MFS02-S-KHC-P1-PNP	Magnetic field sensor straight, cable 0.3 m - M8 connector
14	MFS02-K-KHC-P1-PNP	Magnetic field sensor straight, cable 5 m
15	KAG500	Plug-in connector Straight Cable 5m - Socket M8 (female)
16	KAW500	Plug-in connector Angled Cable 5m - Socket M8 (female)
(17)	S8-G-3	Plug-in connector customizable Straight - Connector M8
18	S12-G-3	Plug-in connector customizable Straight - Connector M12

*in conjunction with pos. 5

RECOMMENDED ACCESSORIES GH6200

Pos.	Order no.	Accessories
1	UB5008AL	* Universal jaw aluminium
1	UB5008ST	* Universal jaw steel
2	WB5008L	* Changeable jaw, loose-part-set
3	WB5008F	* Changeable jaw, fix-part
4	EB5008ST	* Steel adjustment jaw
4	EB5008AL	* Aluminum adjustment jaw
5	APGH6200	Adapter plate
6	UB6200-B	Universal jaw set aluminium
7	DSV1-8E	Pressure safety valve with quick exhaust
8	DSV1-8	Pressure safety valve

*in conjunction with pos. 5

RECOMMENDED ACCESSORIES GH6300

Pos.	Order no.	Accessories
1	UB5010ST	* Universal jaw steel
1	UB5010AL	* Universal jaw aluminium
2	WB5010L	* Changeable jaw, loose-part-set
3	WB5010F	* Changeable jaw, fix-part
4	EB5010ST	* Steel adjustment jaw
4	EB5010AL	* Aluminum adjustment jaw
5	APGH6300	Adapter plate
7	DSV1-8E	Pressure safety valve with quick exhaust
8	DSV1-8	Pressure safety valve
9	NJ8-E2S	Inductive proximity switch - Connector M8

*in conjunction with pos. 5

RECOMMENDED ACCESSORIES GH6400

Pos.	Order no.	Accessories
1	UB5016ST	* Universal jaw steel
1	UB5016AL	 Universal jaw aluminium
2	WB5016L	 Changeable jaw, loose-part-set
3	WB5016F	 Changeable jaw, fix-part
4	EB5016ST	* Steel adjustment jaw
4	EB5016AL	 Aluminum adjustment jaw
5	APGH6400	Adapter plate
7	DSV1-8E	Pressure safety valve with quick exhaust
8	DSV1-8	Pressure safety valve
9	NJ8-E2S	Inductive proximity switch - Connector M8

*in conjunction with pos. 5

Pos.	Order no.	Accessories
9	NJ8-E2S	Inductive proximity switch - Connector M8
10	NJ8-E2	Inductive proximity switch - Cable 5 m
(11)	MFS01-S-KHC-P1-PNP	Magnetic field sensor angled, cable 0.3 m - M8 connector
12	MFS01-K-KHC-P1-PNP	Magnetic field sensor angled, cable 5 m
13	MFS02-S-KHC-P1-PNP	Magnetic field sensor straight, cable 0.3 m - M8 connector
14	MFS02-K-KHC-P1-PNP	Magnetic field sensor straight, cable 5 m
15	KAG500	Plug-in connector Straight Cable 5m - Socket M8 (female)
16	KAW500	Plug-in connector Angled Cable 5m - Socket M8 (female)
17)	S8-G-3	Plug-in connector customizable Straight - Connector M8
18	S12-G-3	Plug-in connector customizable Straight - Connector M12

Pos.	Order no.	Accessories
10	NJ8-E2	Inductive proximity switch - Cable 5 m
11	MFS01-S-KHC-P1-PNP	Magnetic field sensor angled, cable 0.3 m - M8 connector
12	MFS01-K-KHC-P1-PNP	Magnetic field sensor angled, cable 5 m
13	MFS02-S-KHC-P1-PNP	Magnetic field sensor straight, cable 0.3 m - M8 connector
(14)	MFS02-K-KHC-P1-PNP	Magnetic field sensor straight, cable 5 m
15	KAG500	Plug-in connector Straight Cable 5m - Socket M8 (female)
16	KAW500	Plug-in connector Angled Cable 5m - Socket M8 (female)
17)	S8-G-3	Plug-in connector customizable Straight - Connector M8
18	S12-G-3	Plug-in connector customizable Straight - Connector M12


Pos.	Order no.	Accessories
10	NJ8-E2	Inductive proximity switch - Cable 5 m
11	MFS01-S-KHC-P1-PNP	Magnetic field sensor angled, cable 0.3 m - M8 connector
12	MFS01-K-KHC-P1-PNP	Magnetic field sensor angled, cable 5 m
13	MFS02-S-KHC-P1-PNP	Magnetic field sensor straight, cable 0.3 m - M8 connector
14	MFS02-K-KHC-P1-PNP	Magnetic field sensor straight, cable 5 m
15	KAG500	Plug-in connector Straight Cable 5m - Socket M8 (female)
16	KAW500	Plug-in connector Angled Cable 5m - Socket M8 (female)
17	S8-G-3	Plug-in connector customizable Straight - Connector M8
18	S12-G-3	Plug-in connector customizable Straight - Connector M12
	,	

2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 FUNCTIONAL DESCRIPTION



 (\mathbf{I})

GRIPPING COMPONENTS



Universal jaws – UB5000

Can be used immediately or for individual reprocessing

The gripper blanks are available in aluminum (AL) and steel (ST) versions and are installed directly on the gripper using the screws in the scope of delivery. The fits for the centering sleeves are already in place for this purpose. One universal jaw is required for each gripper jaw.

Adjustment jaws - EB5000


For tool-free adaptation of the gripper range

By manually activating the locking mechanism, which is pre-tensioned by a spring, the adjustment jaw can be moved within a grid of detent notches that has a number scale. Depending on the forces and torques that apply, the adjustment jaws are available in aluminum (AL) and steel (ST) versions. One adjustment jaw is required for each gripper jaw.

Interchangeable jaws - WB5000

Enable fast change of individual gripper fingers

For each gripper jaw, a fixed part and at least one loose part set is needed, depending on the number of gripper fingers to be changed. Manual locking via the Torx wrench included in the scope of delivery of the fixed part can take place from two sides.




THE GRIPPING COMPONENTS CAN BE COMBINED!

The gripping components listed above can be combined with each other. For connection to the gripper, the adapter plate (5), which is included in the recommended accessories for the gripper, is required.




GRIPPING COMPONENTS



Universal jaws - UB6000-B

Can be used immediately or for individual reprocessing

The gripper blanks are available in an aluminum (AL) version and are installed directly on the gripper using the screws in the scope of delivery. The fits for the centering sleeves are already in place for this purpose. One universal jaw set is required for each gripper.




Pressure safety valve – DSV

Ensures safe retention of force and position if the system pressure drops

The integrated double check valve, which can be unlocked, retains the system pressure of the gripper in case of EMERGENCY STOP. To ensure the function, the valve must be installed as close to the gripper's air connection as possible. In variant E, two pushbuttons are installed that allow for controlled bleeding of the gripper.


2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 FUNCTIONAL DESCRIPTION

SENSORS




Inductive sensors - NJ

The mounting block is aligned to the cam switch, and the sensor is guided into the mounting block until the required switching distance to the cam switch is reached. Fine adjustment can be made by moving the mounting block again. The sensors are available in versions with 5 m cables with exposed leads and 0,3 m cable with connector, as well as with direct plug orientation.




Clamping bracket – KHA

The KHA can be used as an alternative to installing the sensor via the mounting block. The sensor is inserted into the clamping bracket as far as it will go and secured. Tuning to the cam switch then takes place. Fine adjustment can be made by moving the clamping bracket again.



MFS01



1-point magnetic field sensors - MFS


For non-contact sensing of the piston position

These sensors are installed in the C-groove of the gripper and detect the magnet attached to the piston of the gripper. To ensure use in a wide variety of space conditions, the sensors are available in two variants. While the horizontal MFS02, with straight cable outlet, disappears into the C-groove of the gripper almost completely, the vertical MFS01 is taller, but has a cable outlet that is offset at an angle of 90°. The variants are available in versions with 5 m cables with exposed leads and 0,3 m cable with connector.

2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 FUNCTIONAL DESCRIPTION



CONNECTIONS / OTHER



Centering sleeves


For defined position measurement of the gripper fingers


The centering sleeves are inserted into the fits of the gripper jaws to define the position of the gripper fingers. The centering sleeves are comparable to a pin connection.

2-JAW PARALLEL GRIPPERS WITH LONG STROKE SERIES GH6000 GRIPPER FINGER LENGTH




MAXIMUM GRIPPER FINGER LENGTH






Example 1


Vertical force application point a = 0 mm b = 200 mm






Example 2

Horizontal force application point a = 160 mm b = 0 mm




а

b




Example 3


Maximum permissible projection a = 96 mm b = 160 mm



GRIPPING FORCE AS A FUNCTION OF GRIPPER FINGER LENGTH



Gripping force diagram



Example 4

Resulting gripper finger length for determining the gripping force

a = 55 mm

b = 58 mm

 $x = \sqrt{55^2 + 58^2} = 80 => 435 N$

The specified maximum gripper jaw length in the gripper technical data refers to a vertical (b) alignment of the gripper jaws. With a horizontal (a) overhang, the maximum gripper jaw length is reduced accordingly. The table shows the maximum gripper jaw lengths of the individual sizes. If the required gripper jaw length lies within the tinted area of the gripping force diagram, increased wear must be expected - possibly reduce pressure.

TECHNICAL DATA

	Permissible weight per jaw max	Length of the gripper fingers max. vertical (b)	Length of the gripper fingers max. horizontal (a)
Installation size	[kg]	[mm]	[mm]
GH6000	0.3	150	120
GH6100	1	200	160
GH6200	2.5	250	200
GH6300	3.5	300	240
GH6400	6	400	320